

7917 BEECH STREET N. E. FRIDLEY, MN 55432

USA

Phone 763-784-5531 Fax 763-784-7423 WWW.SUPERSWIVELS.COM

## SUPER SWIVELS LUBRICATION PROCEDURE

Super Swivels are pre-lubricated at the factory. Additional lubrication intervals depend on application. However, a minimum for re-lubrication of every 40 hours is recommended.

- 1. Standard Moly-Lith grease is recommended for Super Swivels in oil and/or water based applications.
- 2. Non petroleum based grease should always be used for Oxygen service. I.e. Silicone based grease (Krytox).

## **DO NOT OVER GREASE**

Using a hand held grease gun, dispense one pump of grease into the grease fitting.

Depress the ball bearing at the end of the grease fitting to allow the excess grease and air to escape.